


Telephone SIGNALER 082 K-MTO 082

FEATURES


- Ideal for the deaf and hard of hearing and for use in noisy/quiet environment.
- Turn lamp ON or OFF via the lamp switch on the **Telephone SIGNALER** lamp will flash with incoming calls even when the lamp is being used.
- Easy installation.
- Telephone ringer can be turned off via the ringer switch on the **Telephone SIGNALER**.
- Complies with UL and FCC requirements.

Telephone Signaler, will signal you if your phone is ringing by turning a lamp on and off automatically.



INSTALLATION INSTRUCTIONS

1. Choose a spot near a wall or baseboard telephone jack.
2. Plug one end of the enclosed line cord into the jack marked line on the base and plug the other end into any working telephone jack.
3. Connect your telephone and lamp to the **Telephone SIGNALER** then plug in the unit.



SAFETY INSTRUCTIONS

When installing this equipment, basic safety precaution should be followed to reduce the risk of fire, electric shock and injury.



1. Read and understand all instructions.
2. **DO NOT** install this product near water.
3. **DO NOT** install this product when thunderstorms are in the area.
4. **DO NOT** place this product on an unstable cart, stand, or table.
5. Objects of any kind other than a telephone plug should not be inserted into this product. This may expose you to dangerous voltage.

Krown Manufacturing, Inc.

3408 Indale Road, Fort Worth, TX 76116
 Voice: (817) 738-2485, TTY: (817) 738-8993
 Fax: (817) 738-1970, E-mail: sales@KrownMfg.com
 Web Site: www.KrownMfg.com